


LEFT CHANNEL

LEFT CHANNEL INPUTS

AUX
TAPE
TUNER 1
TUNER 2
PHONO 1

PHONO 2
MIC.
TAPE HO
MONITOR INPUT
MONITOR
TAPES OUTPUT
NORMAL
S7-2



RIGHT CHANNEL

RIGHT CHANNEL INPUTS

AUX
TAPE
TUNER 1
TUNER 2
PHONO 1

PHONO 2
MIC.
TAPE HO
MONITOR INPUT
MONITOR
TAPES OUTPUT
NORMAL
S7-1

